





HOR.
ST






~ 3/16 PLY.




2" DIHEDRAL
AT OUTSIDE
EDGE




HORIZONTAL
STABILIZER PARTS





BALSA BLOCK




BALSA BLOCK



1/16 DEEP GROOVE

5




1

2

GROOVE
1/16 DEEP




SA



(2) R6 3/32 Balsa



R5 3/32 Balsa



3

GROOVE
1/16 DEEP






VERTICAL
STABILIZER
PART
(ALL 3/16)



(8)



WINGTIP
GUSSET

DIVEDRAL




DRILL & TAP #8-32


BATT. ACC. PAR 1/8




SEAT, Balsa OR FOAM BLOCK




REAR FUS 3/16 BALS



ALIZER (Balsa)



BATT. BOX TOP 3/32 Balsa




(2) REAR FUSE. SIDE
1/8 PLY.

BATT. BOX
SIDE (2)
1/8 PLY.

FOOTWELL LIGHT MOUNT

FUSELAGE TOP
PLY.

FUSELAGE FLOOR



(2) FRONT FUSE SIDE
1/8 PLY.

WING LIGHT
MT. (2)




1/8 PLY.

1/8 PLY.


COVER
BATT.
MOUNT TAB (2)

DECK, 1/8 PLY.
REAR WINDOW




BATT. BOX
TOP MOUNT
1/8 PLY.


1/32 BALSA




MOTOR
MOUNT
COVER
3/32 Balsa



1 inch reference square






REAR
TRAILING
EDGE
DOUBLER

R5

R4

R3

FRONT
WING DOUBLER



3/32 Balsa
7/16 x 15/16 BOTH
WINGS

BALSA TAPERED
TRAILING
EDGE

$3/4 \times 36$

(16)


$1/16$ " BALSA


$2\frac{7}{8} \times 3/4$

OPTION $1/32$ "

$1/8$ SQ.
BALSA
TOP
& BOTTOM R1

$3/16$ DIA.
WOOD
DOWEL







Copyright 2023



and **ModelAviation**

Copying for resale of this drawing without
the written approval or consent of AMA
is expressly prohibited.

R.



SKY ZOOMER

C. GLIDER DESIGNED & DRAWN

BY CLARK SALISBURY

12/2022

Plan No. 1140 Sheet 2 of 2