

Canopy outline-cut from MonoKote trim sheet or similar


Fuselage Top -3/16-inch foam board


Fuselage Bottom-3/16-inch foam board

Wing Template -3/16-inch foam board

Note:
This is a half template.


Mark a center line at 10 inches





Note: Glue nose doublers in place after motor mount installed.

Trim as needed.



Clearance hole for rear of motor

1/32-inch plywood Motor Mount (one required)

1 inch reference squa

on the foam board sheet. Trace this half then flip it over on the center line and trace the other half.

